Large Studio Mixer Operation and Connections

Note: Use indoor antenn coil or optional outdoor antenna (shown.)

i. AM. Outdoor Antenna Range Extender (ATU)

100' of coax cable provided

i.AM. Radio Transmitter
(see instructions in technical manual for transmitter installation and calibration)

1/4" to 1/8" Y cable provided

CD/DVD 1 (optional)

CD/DVD 2 (optional)

Amplified Speakers

DJ Mic
(up to 6 mics may be used)

Use male XLR mic cable provided

Use RCA to phone (1/4") cables provided

Use RCA to phone (1/4") cables provided

Use RCA to phone (1/4") cables provided

MUST be left off

Headphones

Adjust clockwise to set "0" reading on meter.

Equalization is not recommended for broadcast. Set all these knobs in "12:00" position.

Headphone Volume Control

Speaker Volume Control
(turn knob to "0" when mic(s) are on to prevent feedback)

Do Not Press

Set meters for green and yellow. Do not run in red.

Set for proper meter level. (Normally set to "0")

Output Level Master
(leave at/near "0")

Radio Systems, Inc. • 601 Heron Drive • Logan Township, NJ 08085 • Phone: 856-467-8000 • Fax: 856-467-3044 • Email: sales@radiosystems.com